

# Models Rx0L and Rx0LE

## Horizontal Feet Kit Installation Instructions

Use the following instructions to mount the thin client to the horizontal feet kit.



1. Remove the four (4) filler screws.
2. Position the feet to align the thumb screw holes on the feet with the mounting holes on the thin client housing, and slide into place.

3. Insert four (4) thumb screws and snug the screws to hold the feet firmly in place (don't overtighten).



**Caution**

Do not place any objects on the thin client or block the vent holes under the device.



**Note**

Leave at least 12.5 mm between the ventilation holes of the thin client and any solid surface. An enclosed area must have a minimum of 150 square cm of venting or other open area to maintain proper ventilation of the thin client.